

Instruction Book

VMC 100

with Emcotronic TM02

Instruction Book
VMC 100

Ref.-No. EN 7750

Edition 90-10

EMCO Maier Ges.m.b.H.

P.O. Box 131

A-5400 Hallein-Taxach/Austria

Phone ++43-(0)62 45-891-0

Fax ++43-(0)62 45-869 65

Internet: www.emco.at

E-Mail: service@emco.at

emco
innovative machine tools

INDEX

Chapter A: General

o Safety recommendations	A1
o Technical data - machine	A2 - A3
o Technical data - control unit	A4 - A8
o Total dimensions of machine with base	A9
o Machine number, control serial number	A10
o Scope of delivery, standard equipment	A11

Chapter B: Installation of machine and control unit, electrical connection, connection of blow-out device, start-up

1. Installation	B1 - B8
General instruction	B1 - B8
2. Electrical connections	B9 - B15
Mounting of cable from machine to control	B9
Connection of cable to control	B10
Connection of mains	B11 - B12
Fuses	B13
Electrical connection of accessories	B14 - B15
Connection via isolating transformer	B16 - B17
Changing Stepper Motor Board R3D 413 001	B18
3. Connection of blow-out device	B19 - B20
Technical data	B19
Description	B19 - B20
4. Start-up of machine	B21 - B26
Checks before start-up	B21
Switching machine on	B22
Switching machine off	B22
Possible problems during switch-on	B23 - B26

Chapter C: Description of Machine

o Main elements	C1
o Construction features and functional description	C2 - C8
o Machine zero point M	
Tool fixture reference point N	C9
o Reference tool	C10

Chapter D: Working with the machine

1. Working area	D1
2. Operating instructions, programming instructions, zero point shift, tool data	D2 - D7
Overall view of control unit	D2
2.1 Expansion in operation	D3
2.1.1 Swivelling of tool shop, clamping tool in MAN mode	D3
2.1.2 Activation of central lubrication system	D4
2.1.3 Clamping devices ON - OFF	D4
2.1.4 Coolant ON - OFF	D4
2.1.5 Manual traversing of slides	D4
2.1.6 Feed override switch	D5
2.1.7 Determination of rotational direction - main spindle	D5
2.1.8 Speed override - main spindle	D5
2.1.9 EMERGENCY OFF	D6
2.2 Programming instructions	D7 - D9
2.2.1 Programming tool change	D7 - D8
2.2.2 Programming direction logic M50, M51	D9
2.2.3 Programming clamping devices ON - OFF	D9
2.2.4 Main spindle status after tool change	D9
3. Clamping workpieces, clamping devices, zero point shift	D10 - D11
4. Setting of tools, mounting in tool turret, entry of tool data	D12 - D19
5. Working range of tools	D20 - D22

Chapter E: Technological Data

1. General	E1 - E2
2. Determining feed speed and cutting depth	E3 - E4
3. Determining feed speed during drilling in 9S20 and Torradur B	E5
4. Determining rotational speed and cutting speed	E6
5. Tapping	E7
8. Speed - Rating Chart (Main drive spindle)	E8

Chapter F: VMC-100 Accessories

1. Clamping devices for workpieces	F1 - F3
o Clamping bars (basic equipment)	F1
o Machine vice with stop	F1
o Incremental strap	F1
o 3-jaw chuck \varnothing 85 mm	F2
o Clamping device plate for chuck \varnothing 85 mm	F3

2. Clamping devices for tools	F4 - F7
o Collet holder ESX 16	F4
o Milling cutter clamping fixtures	F5
o Holder for taps	F6
o Shell end mill arbor	F7
3. Coolant device	F8 - F9
4. Machine base	F10

Chapter G: Maintenance

1. Maintenance outline	G1
2. Lubricating and oiling	G2 - G3
3. Lubricant and coolant recommendations	G4 - G5

Chapter H: Expansions

Chapter I: List of wearing parts

Chapter J: Readjustment works

o Replacing the step motors	J1 - J2
o Replacing the X-, Y-, Z-slides	J3 - J7
o Readjustment of the slide clearance	J8 - J11
o Measuring the reversal clearance	J12 - J13
o Replacing the door VMC-100 and exchanging the gas spring	J14
o Readjustment of ball snap for tool turret positioning	J15
o Control of carbon brushes on main drive motor	J16
o Changing of the bulb in the machine lamp	J17
o Re-adjusting the collet strok	J18

Chapter A

General

- Safety recommendations A1
- Technical data - machine A2-A3
- Technical data - control unit A4-A8
- Total dimensions of machine with base A9
- Machine Number, control serial number A10
- Scope of delivery, standard equipment A11

General

1. Safety recommendations

Instructions

- * Chip removal may be carried out only with the machine switched off.
- * All claims under the guarantee become null and void if you intervene with the monitoring equipment!
- * Bear in mind the general safety rules for machine tools and CNC machine tools.
- * Only qualified and authorized persons are allowed to use the machine. It has to be protected against unintentional operation (remove switch key).
- * In case of emergency use mushroom push button.
- * In the event of a collision contact the general representative or manufacturer.
- * Chuck workpieces and tools firmly and safely.
- * Always work with perfectly sharpened tools.
- * Condensation water of the blow-out device to be discharged weekly.
- * After working with coolants, those components which have been in contact with the coolant should be cleaned and greased.
- * Coolant level to be checked regularly.
- * Never clean the machine with compressed air.
- * Do not actuate the main switch of the machine during machine operation.
- * Measuring and chucking work may only be carried out when the machine is at a standstill.
- * Do not interfere with the electrical/electronic part of the machine.
- * Read this documentation completely before machine start-up.
- * Be sure that the machine is in perfectly maintained state before machine start up.
- * Tool change procedure to be interrupted in emergency cases only (RESET, EMERGENCY-OFF) since otherwise the tool change system will have to be newly synchronized.
- * Switch off machine only in the defined resting position of the tool change system.
- * Check oil level in the tank for central lubrication at regular intervals.
- * Never place your hand on the top of the side cover on the left while the machine is running.

Technical Data VMC-100

WORKING RANGE

Slide path, longitudinal (X)	185 mm
Slide path, transverse (Y)	95 mm
Slide path, vertical (Z)	200 mm
Workpiece dimension (LxWxH)	190x100x60 mm
Useful Z-stroke for working	100 mm
Distance spindle nose - table surface	95 - 195 mm

MILLING TABLE

Clamping surface ((LxW)	425x125 mm
Max. table load	10 kg
2 T-slots	11 mm
Difference of the T-slots	90 mm

MILLING SPINDLE

Spindel bearing	dia. 40 mm
Type of bearing	angular ball bearing
Clamping fixture similar to DIN 2079	SK 30
Tightening bolt	standard works
Tool clamping	automatic

MILLING SPINDLE DRIVE

Main motor (DC, 100/60% ED)	600/800 W
Type	Direct drive
Speed range (infinitely variable)	10-4000 rpm
Max. torque	8,4 Nm

MACHINING CAPACITY

Drilling capacity in steel (9S20) and feed $s = 0,01$ mm/rev.	dia. 10 mm
Thread-cutting capacity in steel (9S20)	max. M8x10 mm deep

FEED DRIVE

Stepper motor single drive + ball screw spindle	
Feed in X/Y/Z axis	1-2000 mm/min
Rapid feeds in X/Y/Z axis	3/3/3 m/min
Feed force in X/Y/Z axis	1800 N

TOOL SYSTEM

Atool shop	drum with direction logic
Number of tool posts	10
Tightening force	1100 N
Max. adm. tool weight	0,7 kg
Max. adm. tool diameter	60 mm
Cut-to-cut time acc. to VDI 2852	
T1/T2/T3	9,9/9,1/9,1 sec
Tool changing time (without slide operations)	
T1/T2/T3	6,2/5,9/5,9 sec

LUBRICATING SYSTEM

Guideways and ball screw spindles automatic central oil lubrication

COOLANT DEVICE (Option)

Tank volume 80 l

Delivery capacity 15 l/min

Delivery pressure 0,5 bar

PNEUMATIC

Service unit, adjustable for tool turret blow-out unit (with oiler and filter)

Control range 5-8 bar

Supply pressure 6 bar

Connection service unit dia. 10 mm

ELECTRICAL SUPPLY

Main supply 200 V N/PE, 50/60 Hz

Allowable voltage fluctuation $\pm 10\%$ / -5%

Connected load 2,65 KVA

Protection of feed line 12 A

DIMENSIONS

Machine dimensions (LxWxH) 2035x850x1880 mm

Machine weight approx. 300 kg

MACHINE ACCEPTANCE acc. to DIN 8615, part 1

Subject to technical modifications!

Technical Data

EMCOTRONIC TM 02

TYPE OF CONTROL

- * Microprocessor 3-axis-contour control
- * Linear and circular interpolation in all 3 axis (2 1/2 D)
- * Program store for 64 K, open-ended to 128 K (Option)

MONITOR

- * 9" monochrom monitor to show
 - actual position
 - distance left to traverse
 - spindle rpm
 - tool compensation
 - feed
 - further parameters

TECHNOLOGY

- * Input accuracy 0,001 mm (0,0001 inch)
- * Thread pitches 0,01 - 32 mm
- * Feed override 0 - 120 %
- * Spindle rpm override 50 - 120 %
- * Range of interpolation $\pm 9999,999$ mm
- * Tool memory 99 tools
- * Circle interpolation to 360°
- * Circle radius to 20 m

MODES OF OPERATION

- * Manual mode (manual traversing of slides)
- * Execute (working off the input memory)
- * Edit (program input via keys, interfaces)
- * Automatic (Working off NC-programs)

SUBMODES

- * Single block
- * Skip block
- * Dry run
- * Reference point
- * Tool change mode
- * Status
- * Interface

PROGRAM FORMAT

- * Structure according DIN 66025 (ISO 1056)
- * Decimal point input

DATA INPUT / OUTPUT

- * RS 232 C Interface (V24, 150 - 4800 Baud)
- * Tape recorder (Philips MDCR) 600 signs/sec.

Subject to technical modifications!

The Addresses

O Program number (00 - 6999) (7000 - 9999 reserved for graphic)

N Block number(0000 - 9999)

G Codes (00 - 99)

G00 = Rapid traverse
G01 = Linear interpolation
G02 = } Circular interpolation
G03 = }
G04 = Dwell
G25 = Subroutine call
G27 = Unconditional jump
G33 = Thread-cutting (single step)
G40 = Neutralization of the cutter tool correction
G41 = Cutter path correction left hand
G42 = Cutter path correction right hand
G50 = Scaling factor clear
G51 = Scaling factor calling
G53 = Position shift offset 1 and 2 erase
G54 = Position shift offset 1
G55 = Position shift offset 2
G56 = Position shift offset 3,4 and 5 erase
G57 = Position shift offset 3
G58 = Position shift offset 4
G59 = Position shift offset 5, also changeable in
program
G70 = Measurements in inch
G71 = Measurements in mm
G72 = Definition of circular drilling pattern
G73 = Call-up of circular drilling pattern
G74 = Definition of rectangular drilling pattern
G75 = Call-up rectangular drilling pattern
G81 = Drilling, centering
G82 = Drilling, spotfacing
G83 = Deephole drilling with withdrawal
G84 = Threading
G86 = Deephole drilling with chip breaking
G87 = Pocket milling cycle
G88 = Circle pocket milling cycle
G89 = T-slot milling cycle
G92 = Set Register
G94 = Data of feed speed in mm/min
inch/min
G95 = Data of feed in mm/rev.
G98 = Withdrawal to starting plane
G99 = Withdrawal to withdrawal plane

X, Y, Z Absolute coordinates

U, V, W Incremental coordinates

I, J, K Interpolation parameters

P0...P7 } Auxiliary parameters
D0...D7 }

F Feed in mm/min
μm/revolution
Thread pitch in μm

S Spindle speed/Spindle position for M19

T Tool call-up, tool correction (four digits)

L Subroutine number/repetitions (four digits)

jump target

M (00 - 99)	Auxiliary codes
M00	Programmed stop
M03	Spindle clockwise direction
M04	Spindle counterclockwise direction
M05	Spindle stop
M08	Coolant on
M09	Coolant off
M17	Subroutine end
M19	Precise spindle stop
M25	Opening clamping device
M26	Closing clamping device
	} in preperation
M27	Programming dividing attachment
M30	Program end with return to program start
M38	Precise stop on
M39	Precise stop off
M50	Calling off the direction logic
M51	Selection of the direction logic
M90	Calling off the reflexion function
M91	Reflexion on X-axis
M92	Reflexion on Y-axis
M93	Reflexion on X and Y-axes

We reserve the right to make technical modifications and amendments!

Group structure and initial status of the G-functions

Group 0	*	G00: Rapid traverse G01: Linear interpolation G02: Circular interpolation clockwise G03: Circular interpolation counterclockwise G04: Dwell G33: Thread cutting in single step G72: Definition circular boring pattern G74: Definition rectangular boring pattern G81: Drilling, centering G82: Drilling, spot-facing G83: Deep-hole drilling with retraction G84: Tapping G86: Deep-hole drilling with chip breaking G87: Rectangular pocket milling cycle G88: Circular pocket milling cycle G89: Slot milling cycle
Group 2	**	G94: Feed in mm/min or 1/100 inch/min G95: Feed in $\mu\text{m}/\text{rev.}$ or 1/10000 inch/rev.
Group 3	**	G53: Cancellation of offsets 1 and 2 G54: Call-up of offset 1 G55: Call-up of offset 2
Group 4	*	G92: Set offset 5
Group 5	**	G56: Cancellation of offsets 3,4,5 G57: Call-up of offset 3 G58: Call-up of offset 4 G59: Call-up of offset 5
Group 6		G25: Subroutine call-up G27: Unconditional jump
Group 7	<input type="checkbox"/> <input type="checkbox"/>	G70: Measurements in inches G71: Measurements in mm
Group 8	**	G40: Cancellation of the tool path compensation G41: Cutter path compensation left G42: Cutter path compensation right
Group 11	**	G98: Withdrawal to starting plane G99: Withdrawal to withdrawal plane
Group 12		G73: Call-up circular boring pattern G75: Call-up rectangular boring pattern
Group 15	**	G50: Scaling factor clear G51: Scaling factor calling

* effective blockwise

** initial status

☐ Initial status can be established in the user monitor (MON) mode.

Group structure and initial status of the M-functions

Group 0	*	M03: Spindle ON in clockwise direction M04: Spindle ON in counterclockwise direction M05: Spindle stop M19: Spindle precise stop
Group 1	**	M38: Precise stop ON M39: Precise stop OFF
Group 2	* * *	M00: Programmed STOP M17: Subroutine end M30: Program end with return to program start
Group 3	**	M08: Coolant ON M09: Coolant OFF
Group 5	* *	M25: Open clamping device M26: Close clamping device
Group 8	<input type="checkbox"/> <input type="checkbox"/>	M50: Cancellation of the direction logic with bidirectional tool turret M51: Selection of the direction logic with bidirectional tool turret
Group 10		M90: Cancellation of the mirroring function M91: Mirroring on the X-axis M92: Mirroring on the Y-axis M93: Mirroring on the X and Y-axes
Group 11	*	M27: Programming dividing attachment

* effective blockwise


** initial status




Initial status can be established in the user monitor (MON) mode.

Note: The implementation of the individual M-functions depends on the hardware of the machine in question.

Total dimensions of machine with machine table






Machine Number

If you have claims, service parts orders etc. always indicate the machine number.

Machine number



E1-Equipment number
E1-Housing number
Control serial number

Control Serial Number

If you order service parts or in case of claims always indicate control number and control serial number.

Scope of delivery basic equipment

VMC-100 vertical machining center 800 W main motor, speed range 10-4000 rpm., incl. coordinate table vertical column with milling head drive motor, tool shop for 10 tools, stepper motors for 3 axis, sheet metal enclosure, machine lamp taper blow-out device, central lubrication, transparent chip guard door, bench-clamping shoulder, reference tool, handles.

CNC-controlled EMCOTRONIC TM 02 with monochrome screen 9", programming and operating instruction, operating tool.

Basic equipment can differ depending on the country of delivery.

The above mentioned elements are minimal equipment for each country of delivery.

Chapter B

Installation of machine and control unit,
electrical connection, connection of
blow-out device, start-up

1. Installation	B1 - B8
General instruction	B1 - B8
2. Electrical connections	B9 - B15
Mounting of cable from machine to control	B9
Connection of cable to control	B10
Connection of mains	B11 - B12
Fuses	B13
Electrical connection of accessories	B14 - B15
Connection via isolating transformer	B16 - B17
Changing Stepper Motor Board R3D 413 001	B18
3. Connection of blow-out device	B19 - B20
Technical data	B19
Description	B19 - B20
4. Start-up of machine	B21 - B26
Checks before start-up	B21
Switching machine on	B22
Switching machine off	B22
Possible problems during switch-on	B23 - B26

1. Installation

General instructions:

1. Unpacking machine and control unit


The machine and the control unit are each screwed to the pallet by means of four hexagonal screws SW 17. After unscrewing the hexagonal screws from below, the machine and the control unit may be lifted onto the machine and control tables respectively.

Note:

Check machine and control unit for possible transport damage. If you find damages, contact dealer and insurance company.

Check consignment for missing parts - contact dealer if parts are missing (indicate machine number).

If the machine is to be dispatched later, it must be screwed again onto the pallet. In the sketches you can see drilling patterns for screwing machine and control unit onto the pallet.



Dimensions of threaded holes M10 for screwing machine and control unit onto transport pallet.

2. Lifting machine and control unit

Machine:

Approx. weight 172 kg

Control:

Approx. weight 127 kg

Transport:


- * On the left and right side of the machine and control unit there are two bores each, in which handles (2) can be inserted for transporting machine and control unit (see sketch).
- * To avoid damage of machine or control unit during transport, clamp a piece of cardboard (1) between handle (2) and machine or control unit.

Note:

- * Do not insert bars into the bores.

Caution:

Never lift machine on mechanically moveable parts, slides or cable leads.





3. Machine table and control table

3.1 Possible installation of control table

The stand for the control can be turned
90°.

Sizes of tables: See illustration





The stand for the control(1) can be
mounted to the left or to the right
side of the machine stand.
The joint(2), the handle(3) and the
legs(4) have to be mounted in the
correct way.

3.2 Assembly of machine- and control table

Assembly of machine table

- Insert the four foot screws M16 x 60 (11), mount lock nuts M16 (12) and place machine table on supports (13).
- For fastening machine on table use 4 socket head screws M10 x 20 and 2 nuts M10.



Adjusting the Height of the Machine Stand

- Adjust the height with the hexagon screws M16 x 60 (5).
- Counter the hexagon screw with the hexagon nut M16 (6).

Note:


The hexagon bolts can be placed directly on the floor, but it is advisable to place metal sheets (7) underneath.

Attention:


Note 0,5° inclination of table (look page B7).

Assembly of the control table


- 1) Mount casters (2) on legs (1). (Sheet metal screws B4.2 x 13).
- 2) Attach legs (1) to table (7). (With spring washer B8 and nut M8).
- 3) Mount handle (3) with spacer sleeves (8) and socket head cap screws M6 x 60 (9) on table (observe correct side!)



- 4) Attach joint half (4) in such a way that the closed side is on the top. Do not screw tight yet (with spring washers B6 and socket head cap screws M6 x 12).
- 5) Adjust machine table to correct height.
- 6) Insert piece of piping (6) and attach control table to machine table.
- 7) Screw joint half (4) tight.
- 8) Insert line through hole (18) and clamp the line with rope-clamper. Insert line through one of the four fixing holes (19) and clamp the line with rope-clamper. (Adjust swiveling area approx 90°)



4. Fastening of machine and control:




Machine:

For the sealing of the machine against the coolant fluid, a coolant tank (1) is used.

Mounting of the coolant tank:


- Set the coolant tank (1) on the mounted machine base (7) (if there is a bore dia. 30 mm in the machine base it has to be rebored to a minimal dia. 60 mm).



- Remove the sheet metal screws (6) and mount the cover plates (2) with the sheet metal screws 4,2 x 13 (5) and the washers (3).


- If not existing, there have to be drilled four bores dia. 3,5 mm in the machine base.

- Screw in the sheet metal screws (6 and 4) with the washers (3).




Control:

VMC-100: D (2 x with clamping plate)




Notes:



Marking:

To avoid scratching the table surface of the machine base when placing the machine on the table, it is advisable to make marks on the table surface (see sketch).



Inclination of the machine base

The machine should be inclined approx. 0.5° (= approx. 5 mm) forward to ensure complete discharge of the coolant (0.5° to be set with foot screw at the machine base).

The control unit is flush on the left and right side with the machine base.

5. Self-made bases

Machine and control unit must be placed on stable bases. If you do not use original bases, please refer to the recommendations for the base sizes and the bore patterns to screw the machine and control unit onto the bases. Make certain that the self-made control table is made to swivel. On a self-made machine table, two bores for the coolant discharge hoses must be provided.

Recommended table sizes for self-made bases:

Machine:


Length x width x height
1035 x 750 x 830 mm

Control Unit:

Length x width x height
810 x 500 x 830 mm

Recommended table height: 830 mm

Tapped bores for mounting the machine




Dimensions for screwing onto the machine base using two socket head screws M 10 x 20 and nut M 10.

The control unit is to be fixed at the control table using two clamping plates (see page B 6: Mounting of Machine and Control Unit).


2. Electrical Connections

Lay of cables from machine to control

Depending on the position of the control to the machine, the cable conduit is led out from the machine housing left or right hand side.



Remove cover of machine. Dismount part (1), insert all plugs. Mount cable into eye (2). Slide eye (2) into slot of housing. Mount part (1).



Mount eye with cable conduit in the same way into control.

Connecting of plugs to control

Note:


Dismount cover sheet (5) before connecting machine plugs to the control.

Attention!

When connecting or disconnecting, Switch off the the main switch, machine is already connected to main supply, otherwise electr. elements could be destroyed.

- X 23 Step motors
- X 25 Main drive + 220 V
Periphery
- X 32 Tool turret, Bero
Encoder
- X 31 24 V - Periphery

The connection for Interface RS-232C is on the right side of the control.



Note:

Insert plug as straight as possible to avoid damage of the contact pins.

Main Supply

Dates:

Voltage: 220 V single phase, max. fluctuation
of the mains voltage ± 12 V admissible.

Frequency: 50 cy or 60 cy


Fuse: 12 A slow-blowing

Connection value: 2650 VA


Cable: 3 x 1,5 mm² wire section.

Note:

The el. connection of the machine must
be done by an authorized expert.




1. Terminal strip for mains connection
2. Screw fitting for mains cable.
3. Strain-relief clamp



- * Unscrew cap of cable screw fitting (2) and thread onto lead-in.
- * Pass lead-in through cable screw fitting
- * Connection:
 - Connect phase L1 to contact 1 of the terminal strip X 65 (item 1).
 - Connect neutral conductor N to the terminal 4 (blue terminal) of the terminal strip X 65 (item 1).
 - Connect yellow-green core (PE) to the earthing terminal (⊕).
- * Clamp lead-in in strain-relief clamp (3).
- * Screw cap onto cable screw fitting (2).

Fuses



1. Main drive fuse

24V fuse:

If the control lamps (1) on the power component of the transistor setting device do not light up, the 24V fuse (E22) has probably blown (see circuit diagram).

The reason for this may be too high a fluctuation of the mains voltage (max. ± 12 V admissible).

Power fuse:

Fuses F 1 and F 3 A.C.side
(type 10 A slow).

Fuses F 6 and F 7 D.C.side
(type 16 A superfast).

2. Fuses on the motor driver card

(see circuit diagram)

From left to right, fuses for:

E 12...plug, position 4

E 13...power supply for computer

E 14...transformer for feed X,Y,Z

Electrical Connection of the Accessories


The cables for the accessories are connected in the terminal box. A cable connection is enclosed with the respective accessory.

Warning: Before connecting, switch off the machine and pull out the main plug.

The electrical connections may only be made by a specialist.

Electrical Connection of Coolant pump


Remove rear cover of machine. Bores are provided in the terminal box for introducing the cables and making the cable connections.



23..... Position of the cable connection for inserting of the cable of coolant pump into terminal box.

Plate with PG connections VMC-100

X 29



Fixing of cable in terminal box

Phase L1 (black) to PIN 1 of terminal strip X 29. Neutral conductor N (blue) to PIN 9 of terminal strip X 29. Earthing cable PE (yellow-green) to PIN 13 of terminal strip X29.

Connection via isolating transformer

The isolating transformer may serve for

1. Creation of a changeable neutral wire with power supply 3 x 380 V.
2. Transformation of other voltages to 3 x 380 V/220 V.

Ad) item 1:

The main supply must have a changeable neutral wire M_p (= neutral wire N), because some parts of the control and accessories are supplied with only one phase and the neutral wire.

If there is no changeable neutral wire available in the main supply, it is necessary to create a changeable neutral wire. An isolating transformer (adjusting transformer) has to be built between power source and machine.

Recommended isolating transformer:
440/380/220/208 Volt.

Ref.No.: 271 030.

With this isolating transformer a changeable neutral wire is created.

A connection instruction comes with above transformer.


Ad) item 2:

Compare the connections for the specific voltages on the following pages of the instruction.


TRAFO Type DTS 5/5 kVA
Ref. No. 271 030

Transformator Anschlußbeispiele: Transformer Connection Examples:

3 x 208 V 50/60 Hz



3 x 230 V 50/60 Hz



Hinweise:

- Zwischen 50/60 Hz kein Unterschied im Anschluß
- Beim Emcotronic Anschluß muß ein belastbarer Mittelpunktsteiter vorhanden sein.
- Ein belastbarer Mittelpunktsteiter wird durch den Trafo geschaffen.
- Schlechte Netzverhältnisse:
Dauernde Unter- und Überspannungen können durch die $\pm 5\%$ Voltanschlüsse ausgeglichen werden.


Beispiel:

3x440 V Nennwert jedoch dauernde Unterspannung von -5%, das heißt effektive Netzspannungen 3x418 V.


Ausgleich:

L1, L2, L3 der Emcotronic an + 5% anschließen.

3 x 380 V 50/60 Hz



3 x 440 V 50/60 Hz



Remarks:


- No difference in 50/60 Hz cycle supply.
- A neutral wire (N) is necessary for Emcotronic connection.
- With the Trafo the neutral wire (N) is generated.
- Bad Voltage Conditions:
Permanent high or low voltages can be compensated by connecting the Emcotronic to the $\pm 5\%$ Volt connections of the transformer.

Example:

Nominal voltage 3x440 V -5% permanent low voltage therefor effective voltage: 3x418 V.

Compensation: L1, L2, L3 on Emcotronic are connected to + 5%.

Anschlußschema allgemein mit TRAFO General Connection Scheme with TRAFO



Achtung:

Bei Trafoverwendung muß in der Emcotronic N (4) mit PE (\oplus) gebügelt werden.
Bei Direktanspeisung (3x380 V, N, PE) darf N und PE nicht gebügelt werden.


Attention:

Using the Transformer N(4) and PE (\oplus) have to be jumped in the Emcotronic.
No jumpering of N (4) and PE (\oplus) if no Transformer is used (ie. Direct Power Supply with 3x380 V, N, PE).


ATTENTION !!!

Changing Stepper Motor Board R3D 413 001

Before mounting the board R3D 413 001 the Dip-switches for current adjustment and feed directions have to be set in correct way. Otherwise the board will be disturbed.



Adjusting feed directions



3. Connection of blow-out device

During each tool change the blow-out device blows out the tool taper fixture.

Therefore, dirt in the tool taper fixture and inaccurate clamping of tools is avoided.


1. Technical data of compressed air supply

Maximum admissible pressure: 10 bar

Recommended working pressure: 6 - 7 bar

Connection: Compressed air hose \varnothing 10 mm

2. Description



- 1 Connection for compressed air hose \varnothing 10 mm
- 2 Manual slide valve
- 3 Filter with water separator
- 4 3/2 valve
- 5 Screw for draining water from the water separator tank

2.1. The manual valve:

Function:

By means of the manual valve, the air supply can be switched on and off.

Slide upward: valve open

2.2. The filter with water separator

Function:

Separation of air from water and dust.

2 Options for draining water from separator tank:

Option A:

- * Open screw (5) slightly → water flows out under pressure.
- * Tighten screw again.

Option B:

- * Switch off compressed air supply (at manual slide).
- * Completely unscrew the screw (5) - water flows out.
- * Screw in again screw.

Maintenance:

Check separator tank for water.


Weekly check.

2.3 The 3/2 valve

Function:

During tool change, the 3/2 valve is actuated electrically and controls air supply for blow-out of tool taper fixture.

The 3/2 valve is equipped with a screw (1) for manual actuation of air supply.



Procedure:

Press in screw (1) using a screw driver and turn from position 0 to 1.


4. Start-up of machine

Checks before start-up

- * If the machine is connected electrically, it can be started up. Before initial start-up, eliminate the rust preventive and oil all bare metal parts except spindle taper and tool taper.
- * Check oil level for central lubrication. If there is no oil in the lubricant tank, the central lubrication system has to be deaerated after filling in the oil.
- * Check contents of coolant device.
- * Note all other maintenance instructions (see chapter G).
- * Press the lubricant button and the slideways will be lubricated.
- * Switch on air supply (hand slide) for the blow-out device.

Switching machine on

8.7.92



Possible problems during switch-on

- * ALARM A130 (see loading MS data)
- * ALARM A050/A060 (see tool turret alarms on the following pages).

Switching machine off

The machine is switched off by means of a key-operated switch.

Please note:

Caution!

The key-operated switch may be switched off only if the main spindle is stopped, otherwise the main drive fuses may melt.

Do not switch off during tool change or during a slewing operation, otherwise the drum is in an undefined position when switching on again → Alarm 060. See page B 24!

Possible problems during switch-on

1. Alarm A130 (incorrect machine status data for axis control unit)

Note:

If the machine has not been switched on for more than three months, the MS data (machine status data) may no longer be available in the buffer memory. In this case, the screen displays alarm 130. The accumulator for puffer action of these data is reloaded only with the machine switched on.

Furthermore, unintelligible values may be displayed in the position shift offset (PSO) and in the tool data offset (TO).
In addition, also stored user programs may be lost.

Measures:

Load machine data from cassette or punched tape.

Loading machine status data (MSD)







MS-data (= MSD) - is the abbreviation of the English term "machine status data".

The machine is delivered with one machine data cassette containing the MS data.







The cassette with the MSD is set backwards in the electric box door of the basic machine.

During the loading procedure all system data are loaded into the internal machine data memory.


Loading machine data from cassette

		Switch to EDIT mode, insert cassette.	
		Activate soft key CASSETTE PORT. The control reports in cassette operation (interface 0).	
			 The data are loaded.

Loading machine data from punched tape via RS 232:

		Switch to EDIT mode, insert punched tape.	
		Activate soft key RS 232 PORT. The control reports in RS 232 operation (interface 1).	
			 The loading procedure is started.

2. Alarm A060 TOOL TURRET NOT READY



After switching on the machine, alarm 460 "REFERENCE POSITION NOT ACTIVE" appears and possibly alarm 060 at the same time.

Using the key  the auxiliary drives are switched on.

By pressing the CYCLE START key the reference point is approached.

If alarm 060 "TOOL TURRET NOT READY" also appears during switch-on, the tool positions on the tool shop are unknown to the control unit. Therefore, after approaching the reference point, the following must be noted:

Measures:

If necessary, acknowledge alarm with C.E. In MAN mode press MAN JOG and swivel button jointly. The tool shop swivels in tool position 1 and is synchronized.

Note:

After switching off the main switch, the control unit stores the last tool position so that this procedure need not be carried out when the machine is switched on again.

3. Alarm A060 during switch-on followed by alarm A050 during CYCLE START in reference submode


If A050 appears when reference point is approached, the tool shop is not in "clamping position". (Tool bevel regarding main spindle).


Explanation:

A proximity detector controls the position of the tool shop and triggers alarm 050 if the tool shop is in the wrong position. In this wrong position a Z-movement must not occur, as this might lead to collision in Z-direction.

This may happen e.g.:

- * If you have manually turned the tool drum out of its snap-in position.
- * If the tool drum was turned by a mechanical collision.
- * If the swivelling process was interrupted. (EMERGENCY STOP)
- * If the ball notch was clamped too less, so that the drum is not in the exact position. Adjust ball notch. (see adjustment works).





Measures:

- * Turn tool shop so that proximity detector (1) is above the slot in the (2) control plate (tool shop snaps in).

* Cancel alarm A050 by C.E.

* Approach reference point.

* The screen displays the dimensions XMN, YMN and ZMN.

* Start swivelling procedure in manual mode - position 1 is swivelled in and the tool change system is ready for operation.

Please note:

The reference point N of the tool clamping fixture is in the spindle axis of the front side of the reference tool.

Note:

Never switch off the control unit during the swivelling procedure or in undefined position of the tool shop.

When switched on again, the actual position of the tool shop would be unknown to the control.

Alarm A060 appears!


Remedy:

- Turn tool shop manually, when machine is switched off.

- Switch on machine, approach reference point.

Remarks:

Swivelling in manual mode using keys



is not possible as long as an alarm is displayed. If necessary, it has to be acknowledged first using



Chapter C

Description of Machine

- Main elements C1
- Construction features and functional description C2 - C8
- Machine zero point M C9
- Tool fixture reference point N C9
- Reference tool C10

Machine Description

Main Elements

(Picture in preparation)

- 1 Machine base with chip tray and coolant drains
- 2 Cross slide
- 3 Longitudinal slide
- 4 Vertical slide
- 5 Tool shop
- 6 Main motor
- 7 Coolant line
- 8 Control EMCOTRONIC TM 02
- 9 Machine table
- 10 Control table

Construction- and function principle

Machine Base:

Welded metal sheet construction with integrated chip tray, coolant drip pan and workpiece collecting tray.

The machine stand:

The machine stand is manufactured from high-grade grey cast iron with heavy ribbing. This ensures high stability and vibration-free behavior. The slide units are mounted on the machine stand.

The slides/slide guides:

The slides are also made of grey cast iron. The ground dovetail guideways of large dimensions guarantee optimum guidance conditions of the slides, little surface pressure and therefore long service life. The vertical slideway is hardened.

Each slide is provided with two adjustable tapered edges to allow easy adjustment of slideways without problems.

The dovetail guideways are oiled automatically by the central lubrication system.

Feed Drives:

The slides are moved by step motors via high precision ball bearing spindles.

The large-sized spindles together with stiff spindle nuts and play-free axial bearing guarantee high positioning and working accuracy.

Measuring/Control System of the Feed Drives

By approaching the reference point we fix the position of the machine zero-point M in relation to the tool mount reference point N.

In traverse operation the slide position is controlled each permanent.

If the drive is out of step, an alarm is indicated. The reference point has to be approached.

Proximity detectors for approaching the reference point

Proximity detectors are mounted in the X-, Y and Z-axis which signal the reference point position of the respective slides to the computer.

Start is effected by pressing CYCLE START in the REFERENCE submode in MANUAL-mode.

The main motor with torque pick-up

The D.C. motor has a speed range of 10-4000 rpm. A torque pick-up is mounted on the main motor. The torque pick-up has two functions:

1. Controlling the rotational speed of the main spindle
2. Positioning the pinion angle for swivelling the tool shop.

Main spindle:

The main spindle is mounted in two deep-grooved ball bearings.

The bearings are greased for life and maintenance-free. In the main spindle, bores for blow-out of the tool taper are provided.

The main spindle is directly driven via the D.C. motor by a toothed belt.

Safety Devices

The main spindle only runs when door is closed (manual mode, automatic mode)

If door is opened during operation, main drive and slide stop.

The central Lubrication System

The longitudinal and cross slides are supplied with slideway oil by the central lubrication system.

The pump is switched on for 5 seconds after 10 m of slide travel. This interval and the activation period are established by the works.

The coolant device:

The coolant hose is mounted on the machine.

There is a hand slide at the coolant hose for turning the coolant flow on and off.

Actuation is via M08 coolant (on) and M09 coolant (off) through the control unit or using the respective key.

The tool shop


In the tool shop 10 tools may be clamped. The dividing procedure, clamping and releasing of tools can be carried out in the manual mode or via the CNC program. The procedure is described on the following pages.

Tool change procedure (principle)

Releasing of the tool, swivelling of the tool shop and clamping of the tool is a complete cycle.

Procedure:

1. The pinion on the main spindle is turned in engagement position to the pinion of the tool shop (control by the torque pick-up on the main motor).
2. The Z-slide moves upward. The clamping device for the tool is opened by a hoop. The tool shop is supported. The slide moves upward until the tool taper is free. The drum can turn around.
3. Swivelling to the tool location selected (command via control unit, command control by means of torque pick-up. Report of exact angle position by proximity detector 2).




4. Milling head is lowered. Tool is clamped.
5. Tool shop and milling head remain in Z-position (reference point). Tool change is finished.


Note:

The up and down movement of the milling head is controlled by the proximity detector of the Z-feed drive.


Clamping process during tool change



- * Via the main motor the pinion (8) is placed in snap-in position for the toothed ring (9) for tool shop swivelling.
- * A proximity detector controls the position of the tool shop. If the tool shop is not in clamping position, alarm 050 is given (in any non-clamping position a Z-travel movement must not be carried out).
- * Milling head (1) and tool shop (2) travel together in +Z-direction.
- * The clamping hook (3) is then actuated via cam travel A and the clamping screw (4) of the clamping hook presses onto the spring washer group (7) in the milling head via the setbolt (5).



- * The spring washer group is clamped entirely from the junction of cam travel A and cam travel B. From this point the the collet is opened completely.
- * After the collet is opened completely, the tool shop is supported by two ball bearings (10). The tool shop no longer carries out a traverse movement in +Z-direction.
- * The milling head moves on in +Z-direction. During the traversing range B of the cam, the collet remains completely open and the tool moves out of the milling spindle.



* During the traversing range C of the cam, the collet (6) is closed again and the clamping screw (4) of the clamping hoop (3) rises again from the pressure bolt (5).

* In the uppermost position the pinion (8) engages in the toothed ring (9) for tool shop swivelling. Then the tool shop is swivelled via the main motor.

* After swivelling the tool shop, the milling head moves downwards again (-Z-direction).

* During downward movement, the tool-clamping taper of the milling spindle is blown out to avoid any dirt accumulation in the tool clamping fixture and therefore guarantees perfect clamping of the tool tapers.


* The collet is opened again via cam travel C.

* During cam travel B, the collet remains completely open.

* After the tool taper is moved entirely into the tool clamping taper, the collet is clamped again via cam travel A.

* Via a proximity detector it is reported to the control unit if the tool taper fits correctly into the tool taper clamping fixture or not.

Tool change control by proximity detectors




Proximity detector 1:

Proximity detector 1 is used for synchronization of the tool shop position when the machine is initially switched on.

Procedure:

By pressing the key for swivelling + MAN JOG, the tool shop turns until the cam in the tool shop is above proximity detector 1. Now the angle position of the tool shop and the position of the individual tools is known to the control unit. The cam is arranged in such a way that tool position 1 is in working position. When switching on again, the tool position, which is actually swivelled in, is known to the control unit. Resynchronization is necessary only if the tool shop was turned into an undefined position either manually or by a collision.



Proximity detector 2:

Proximity detector 2 controls the exact angle position of the tool shop after each swivelling move. If the swivelling position is not reached exactly, alarm A050 appears. In an alarm 050 position the tool would be in a bevel position with reference to the main spindle. Collisions would result during clamping.

Remedy:

- * Turn tool shop manually so that proximity detector (2) is above the groove in the control plate (4).
- * Cancel alarm 050 using C.E.
- * Swivel tool shop.


Note:

Never switch off the control unit during the swivel process of the tool shop. When switching on again, the actual position of the tool shop will not be known to the control.

Alarm A060 appears!

Remedy:

- Reset tool shop manually with the machine switched off
- Switch on machine, approach reference point.
- Synchronize tool change system in manual mode in a single swivelling process.



Proximity detector 3:

Proximity detector 3 controls the correct position of the tool shop with reference to the milling head. The tool shop runs on a slide and is supported by springs. In case of spring break the tool shop would fall down. This situation would be reported by proximity detector 3.


Main function of proximity detector 3:
Detecting problems during tool clamping.

The Machine zero point M ⊕

The tool-holding fixture reference point N ⊕

Position of M: ⊕

Left front edge of the
table surface



Position of N: ⊕

N lies in the spindle axis
at the front of the main spindle.

Explanations:


- 1) The machine manufacturer determines the position of M and N on the machine.

Decisive factor for the ⊕
determination of position M:


It should be possible to easily
measure the dimensions up to the
workpiece zero point.

- 2) The machine manufacturer measures the distances between M and N and loads them into the control unit.
Therefore, the control unit recognizes the distances M to N. If the main spindle is freely accessible, point M on milling machines is determined at the front side of the milling spindle. In the case of the VMC-100 the front side is not easily accessible, therefore N is determined at a reference tool.

Reference tool



- * A reference tool is delivered with the machine.
Point N is situated in the rotation axis at the front side of the reference tool.
- * If no zero point shift is active and no tool compensation is selected, the screen displays the dimensions $M \rightarrow N$.
- * Tool lengths are defined from point N.
- * This reference tool is necessary for direct tool length take-over when touching a dial gauge.
- * Point N lies 30 mm below the lower plane surface of the ball bearing.




Chapter D


Working with the machine

1. Working area	D1
2. Operating instructions, programming instructions, zero point shift, tool data	D2 - D7
Overall view of control unit	D2
2.1 Expansion in operation	D3
2.1.1 Swivelling of tool shop, clamping tool in MAN mode	D3
2.1.2 Activation of central lubrication system	D4
2.1.3 Clamping devices ON - OFF	D4
2.1.4 Coolant ON - OFF	D4
2.1.5 Manual traversing of slides	D4
2.1.6 Feed override switch	D5
2.1.7 Determination of rotational direction - main spindle	D5
2.1.8 Speed override - main spindle	D5
2.1.9 EMERGENCY OFF	D6
2.2 Programming instructions	D7 - D9
2.2.1 Programming tool change	D7 - D8
2.2.2 Programming direction logic M50, M51	D9
2.2.3 Programming clamping devices ON - OFF	D9
2.2.4 Main spindle status after tool change	D9
3. Clamping workpieces, clamping devices, zero point shift	D10 - D11
4. Setting of tools, mounting in tool turret, entry of tool data	D12 - D19
5. Working range of tools	D20 - D22

1. Working area



The sketch shows the possible traversing range in X and Y direction.



Traversing range in Z-direction:

Effective working stroke 100 mm. The dimensions 149 (N to table area) and 179 (lower plane surface of ball bearing to table area) refer to the uppermost working position (=reference point position).

Note:


The working area proper of the tools is in accordance with the length of the tools clamped. See pages "Working areas of tools".

Software limit switch:

In the manual mode the control unit reports "Entered Caution Zone" 10 mm before and up to the reaching of the final length. In this area the slides move with slow safety feed.

2. Operating instructions, programming instructions, zero point shift, tool data

Overall view of control unit



2.1 Operating instructions

Operation of control and programming is described in the operating instruction Emcotronic TM 02, Ref.No. 7765 and in the programming instruction TM 02 Ref.No. 7766.

Introductory remark:

On the symbol insert of EMCOTRONIC TM 02 it is shown which state of the manual function keys is activated or deactivated.

The activated state lights up.

2.1.1 Swivelling of tool shop

If both key are pressed quickly

- * the clamped workpiece is released
- * the tool drum moves on by one position
- * the tool is clamped



Pressing keys longer


- * the clamped tool is released
- * the tool drum turns round until you release the keys (or one of the keys)
- * the tool is clamped

Note:


By setting G08 Bit 0 = 1 (High), switch-over to single-key operation may be carried out (see operator monitor in programming instructions TM 02).

Direction of rotation:

If the SHIFT key is not active (symbol on symbol insert does not light up) - swivelling in the direction of increasing position numbers.



If the SHIFT key is active, the respective symbol on the symbol insert lights up - swivelling in the direction of decreasing position numbers.



2.1.2 Activation of central lubrication system



If you press the lubricating key, the central lubrication system is activated.

The pump switches on for approx. 5 sec. and supplies the guideways with oil.

With an active key the respective symbol lights up on the symbol insert.

Note:

The lubrication system is activated automatically by the control unit every 10 meters of slide travel.

2.1.3 Clamping devices ON - OFF




This function is not activated at present.

2.1.4 Coolant ON - OFF



By pressing this key the coolant pump is switched on or off. With an active key the respective symbol lights up on the symbol insert.

2.1.5 Manual traversing of slides




By pressing the **MAN. JOG** keys

and the respective arrow key the slides can be moved manually into the direction desired.

Note:

- * Mind that in EDIT mode you can change the tool compensation data in the tool data memory (TOOL DATA) by using the arrow keys.
- * By using the arrow keys (1,2) in STATUS submode you can turn the pages forward and backward.


2.1.6 Feed override switch




With the feed override switch the feed speed can be modified during traversing slides.

2.1.7 Determination of rotational direction - main spindle


Representation of symbol line



Main spindle ON in clock-wise direction




Main spindle ON in counter clock-wise direction



Main spindle OFF




2.1.8 Speed override - main spindle



By means of this key you can change the speed (mind the percentage value at the symbol line of the screen).

2.1.9 EMERGENCY - OFF



Consequences:

- slides stop (also with G33, G84)
- main spindle OFF
- coolant OFF
- tool way compensation called off
- active tool data/PSO data called off.
- Reference point might eventually be lost.
- Program jump to N 0000


Restarting the machine:

- unlock EMERGENCY - OFF key (turn to right)
Machine and control unit are switched on again.
- If the tool shop is in undefined position (see possible problems during switch-on).
- If necessary, approach reference point (alarm 150/460).
- clear EMERGENCY - OFF situation (set program right, change broken tool etc.)

2.2 Programming instructions

2.2.1 Programming of tool change

Tools are programmed under the T-address using a 4-digit number.



Note:

- * You may allocate any compensation number to any location.
E.g.: T03 78
However, it is clearer for your program if you allocate numbers which are remembered easily.
E.g.: T03 03 or T 03 13 or T03 23
- * You may also allocate different compensation values successively to a tool.
E.g.: T03 03/T03 04/T03 05
- * When programming T00 00 there is no swivelling, only offset call-off.
- * If a tool location is programmed larger than 10, an ALARM is given.

Call-up (Syntax rules)

When calling up a new T-address the next traverse movement has to be a G00 block, otherwise alarm 490 will occur (only valid with actual change of tool offset).


Example: Call-up in the same block with G00

N 100 / G00 / X.../Y.../Z.../ T02 02

Example: After the T-call-up a G00 traverse command follows

N 100 / T02 02
N 110 / G94 / F 130
N 120 / G54
N 130 / G00 / X.../Y.../Z.../

Calling-off the Tool(length) Compensation



T..00

If the reference number T.. 00 is programmed, the coordinates (measurements) system refers to the reference point for the tool mounting.

Alarms in connection with tool call-up

1. T-call-up not in connection with G00 transverse instruction.
2. Unacceptable call-up T00 04:
Tool number \neq 01 - 10
T02 00 is admissible, the correction values are automatically zero (setting tool).

2.2.2 Programming direction logic, M50, M51

M50, M51 belong to group 8 of M-functions. These are self-holding functions. The switch-on status may be determined on the operator screen 011 Bit 3.

M50 calling off the direction logic

The tool turret turns in one direction (counter-clockwise).

M51 selecting the direction logic

The tool turret swivels in the shortest way to the programmed tool (this switch-on status is set by the manufacturer).

Determining the switch-on status on the operator screen

011 Bit 3 = 0 (LOW) -> M50

011 Bit 3 = 1 (HIGH) -> M51

The entry of a word for 011 Bit 3 does not effect a change of the actual M50/51 state, only the switch-on state is determined. A modification of the actual M50/51 state can be effected by execution of M50 and M51 EXECUTE mode or directly from the NC program.

2.2.3 Programming clamping device open/close

M25 open clamping device

M26 close clamping device

These functions are in preparation.

2.2.4 Main spindle status after tool change

Example:

N 100 M03 S1000

:

N 150 T02 02

N 160 M04 S500

:

For the tool change procedure the main spindle is required. After termination of the tool change procedure in N 150 the former main spindle status (M03 S1000) is reset automatically, in N 160 (after speeding up the spindle to M03 S1000 in N 150) the desired value M04 S500 is carried out only then.

Remedy: (for time optimization)

N 100 M03 S1000

:

N 150 T02 02 M04 S500

:

If prior to tool change M05 is not active and after tool change a modified main spindle status is desired (rotary direction or speed) this new status has to be programmed in the same NC block as the T word in order to avoid needless main spindle operations.


3. Clamping of workpieces, clamping devices

zero point shift

For clamping workpieces, standard clamping devices (incremental straps, machine vice, clamping bars) are offered.

For special kinds of clamping the clamping devices are to be manufactured by you. Table dimensions (T-groove dimensions for mounting special clamping devices on the milling table) are described in the chapter "Clamping Devices for Workpieces".

Traversing range of the center axis of the milling cutter with reference to the milling table




If you mount a clamping device, you have to take care that the clamped workpiece is placed in the traversing range of the milling cutter. The traversing range is illustrated in the opposite sketch.

Also note the height of the workpiece in clamped state when mounting the tools (see mounting of tools).

Maximum workpiece heights

The effective traversing range of the milling cutters in Z-direction is 100 mm.


Maximum and minimum machining height are given for each tool clamped. See illustrations of milling clamping fixtures with milling cutters $\varnothing 16$ and $\varnothing 10$ mm.



Zero point shift, take-over of data

The machine zero point is in the position indicated.

The dimensions for zero point shift may be measured with a ruler, gauge etc. and entered in the position shift offset.



For exact take-over of PSO data you may touch the workpiece.

Input of PSO data is described clearly in the programming instructions EMCOTRONIC TM 02.

4. Setting of tools, mounting in tool turret, entry of tool data

Clamping tools in the collets:


Milling and boring tools may be clamped in collet chucks, milling cutter clamping fixtures and shell end mill arbors. Taps are clamped in holders for taps. You can find more detailed information in the chapter "Clamping Devices for Tools".

When mounting tools, mind their different lengths.
Some hints: The effective working stroke of the Z-axis is 100 mm. If a tool with a protruding length of 80 mm (measured from the lower plane surface of the ball bearing) is clamped, the table area of the machine is reached.


Note:

Do not clamp tools longer than 80 mm, otherwise the risk of collisions during swivelling is increased.

See also surveys on pages D20, D21, D22.



Mounting tool collets on the tool shop plate




- * Turn clamping screws (1) until tool collets can be inserted (mind the flat screw head).
- * Tighten clamping screws.
Note: If clamping screws are tightened, the collets in the clamping fixture have a small clearance. The clearance is necessary so that there is no overstrain of tool shop plate/milling spindle if the tool is clamped in the milling spindle (to prevent false gripping).
- * Swivelling the tool shop for mounting collets in manual mode.

Note:

Never swivel the tool drum by hand while mounting tools on the tool shop. The tool shop might not be in "clamping position" and if the machine is switched on, alarm 060 will be triggered. The tool shop would then have to be turned by hand into the correct position (see Start-up of Machine - possible alarms).

Measuring the tool length Z using the slide gauge



The tool clamping reference point N lies 30 mm from the lower plane surface of the ball bearing.

Measure from the ball bearing to the tool tip - subtracting 30 mm - to get the Z-measure.

This Z-value is entered in the TOOL DATA register.

Please note:

Z is always a negative value since the tool tip is always in -Z-direction.

The drawing example

Z = -55.000 is entered in the TOOL DATA register.

Note:

This method is not very accurate. You will have to make corrections after measuring a workpiece.

Direct take-over of tool lengths

With EMCOTRONIC TM 02 it is possible to take over the tool lengths directly. This is a very accurate and comfortable method.

Option 1: Touching with dial gauge

- * Select manual mode.
- * Mount reference tool and swivel in.
- * Touch dial gauge with reference tool. Set dial gauge to zero.



TO	0	0
ENTER		

The height H is stored in the control by TO 00 ENTER.

- * Swivel in the tool to be measured and touch dial gauge (gauge must show 0).



TO	0	1	Tool correction number wanted
ENTER			

The tool length Z is stored under tool correction number T..01.




Option 2: Scratching a trial workpiece

1. Measure the height (H) of the trial workpiece which has to be scratched.




2. Set manual mode.

Traverse to distance H with reference point.
(screen display)




The dimension H is stored.


3. Swivel in tool and scratch workpiece surface.



The dimension Z is stored under correction number T..01.



Correction of the length data



EDIT:

TOOL DATA

DISTANCES
[MM]

	X	Z	R	L
00:	0.000 :	0.000 :	0.000 :	0
01:	0.000 :	<u>-35.000</u> :	0.000 :	0
02:	0.000 :	0.000 :	0.000 :	0
03:	0.000 :	0.000 :	0.100 :	0
04:	0.000 :	0.000 :	0.000 :	0

* Imagine the coordinates system in the target value.

* Measure difference between target value and actual value:

$$Z = -5 \text{ mm}$$

* Add this value with the correct sign to the value in the tool data memory.

$$Z = 35 \text{ mm} + (-5\text{mm}) = -40 \text{ mm}$$

* Write this value into the tool data memory.




EDIT:

TOOL DATA

DISTANCES
[MM]

	X	Z	R	L
00:	0.000 :	0.000 :	0.000 :	0
01:	0.000 :	<u>-40.000</u> :	0.000 :	0
02:	0.000 :	0.000 :	0.000 :	0
03:	0.000 :	0.000 :	0.100 :	0
04:	0.000 :	0.000 :	0.000 :	0

Example:




Z actual = 35 mm

Z info = 35 mm

Z actual is the same as
Z INFO in the tool data memory

Measurement in drawing (10) and on
workpiece must be the same.



Z target

Z actual

Z info

Z actual

Z actual is not equal to Z INFO:

Consequence: Wrong measurements on
workpiece (15 mm instead 10 mm)

Correction of tool lengths

By measuring the workpiece, you are able to detect any errors caused by inaccurate tool data.

Correction:


- * delete values
- * enter corrected values
- * incremental change of Z-value

Incremental Changing of the PSO and T0 Data


If you have selected the respective register (PSO or T0) and the offset number or tool number, you can change the X, Y and Z values with the JOG keys.


The illustration shows with which keys the values can be changed.


MANUAL-JOG (EMCOTRONIC TM02)



5. Working areas of tools







Chapter E

Technological Data

1. General	E1 - E2
2. Determining feed speed and cutting depth	E3 - E4
3. Determining feed speed during drilling in 9 S 20 and Torradur B	E5
4. Determining rotational speed and cutting speed	E6
5. Tapping	E7
6. Speed - Rating Chart (Main drive spindle)	E8

1. General

1.1 Cutting speed (V)

$$V \text{ (m/min)} = \frac{d \text{ (mm)} \times \pi \times S \text{ (rpm)}}{1000}$$

V = Cutting speed

d = Diameter of workpiece

S = Main spindle speed

The maximum cutting speed depends on

- Material of workpiece:

The higher the strength of the material,
the lower the cutting speed.

The charts contain the following data:

V = 44 m/min for aluminium (Torrador B)

V = 35 m/min for soft steel
soft plastics

V = 25 m/min for tool steel
hard plastics

- Material of tool:

Carbide tools allow higher cutting speed
than HSS tools.

The values given in the charts are for
HSS tools.

1.2 Speed (S)

You calculate the speed of the milling
spindle from cutting speed and diameter
of milling cutter.

$$S \text{ (rpm)} = \frac{V_s \text{ (m/min)} \times 1000}{d \text{ (mm)} \times \pi}$$

1.3 Feed rate and depth of cut

F , = Feed rate (mm/min)

t = Depth of cut (mm)

Generally: feed rate and depth of cut depend on

- workpiece material
- performance of machine and
- geometry of milling cutter.

Material of workpiece:

The higher the strength, the lower the F and t values.

Rating of the machine

The higher the rating, the greater the feed and the depth of cut (limitations: cutter geometry).



The tables gave guide values for the VMC-100.

Relationship between F and t :


The bigger t is, the smaller F is and vice versa.

2. Determining the feed rate and depth of cut during milling



2.1 Face milling of aluminium (Torrador B) at $v = 44$ m/min




You can also proceed as follows:




2.2 Face milling of steel (9S20) at $v = 35 \text{ m/min}$



You can also proceed as follows:



3. Determining the feed rate
during drilling in 9S20 and Torradur B




Material: 9S20


Drill diameter = 9 mm

Feed rate = 90 mm/min


4. Determining the speed and cutting speed



Determining the speed:



Determining the cutting speed:



5. Tapping

Threads M3 to M8 can be machined on the VMC-100. With M8 threads the thread depth must not exceed 10 mm.

With all other screw taps you can produce any boring depths desired.

When tapping you must not use feeds higher than 1500 mm/min. With higher feeds the length compensation of the toolholder would be exceeded. So you have to select the spindle speed that way that the feed of 1500 mm/min is not exceeded for the threadpitch used.


Example:

Thread M8 -> pitch 1,25

$$\text{Spindle Speed } \left[\frac{\text{U}}{\text{min}} \right] = \frac{\text{Max. feed } [\text{mm/min}]}{\text{Pitch } [\text{mm}]}$$

$$\text{Spindle Speed} = \frac{1500}{1,25} = 1200 \frac{\text{rev}}{\text{min}}$$

6. Speed - Rating Chart (Main drive spindle)



Chapter F

VMC-100 Accessories



- | | |
|--|---------|
| 1. Clamping devices for workpieces | F1 - F3 |
| o Clamping bars (basic equipment) | F1 |
| O Machine vice with stop | F1 |
| o Incremental strap | F1 |
| O 3-jaw chuck ϕ 85 mm | F2 |
| o Clamping device plate for chuck ϕ 85 mm | F3 |
| 2. Clamping devices for tools | F4 - F7 |
| o Collet holder ESX 16 | F4 |
| o Milling cutter clamping fixtures | F5 |
| o Holder for taps | F6 |
| o Shell end mill arbor | F7 |
| 3. Coolant device | F8 - F9 |
| 4. Machine base | F10 |

VMC-100 Accessories

1. Clamping devices for workpieces

Table area L x B: 420 x 125 mm


Dimensions of the T-slots



Clamping bars (Basic equipment)

The clamping bars are mounted directly onto the slide depending on the workpiece in question. The workpiece is clamped with the stud bolts.

Height of clamping boars 12 h 11.
Total height with clamping screws 22 mm.




Machine vice with stop

Width of jaw: 60 mm

Clamping capacity: 60 mm

Height up to guide way of clamping jaw 20 mm, total height 48 mm



Incremental strap

Height: 60 mm

For clamping a workpiece you need at least two incremental straps.

The 3-jaw chuck \varnothing 85 mm

The 3-jaw chuck \varnothing 85 mm allows clamping of cylindrical pieces.


Mounting:

- * Screw intermediate plate (1) onto the machine table (2) using enclosed clamping screws (mind the working area of the machine).
- * Mount the 3-jaw chuck (3) \varnothing 85 mm on the intermediate plate using the three enclosed flat head screws M 5 x 40 (4).

Mind:


After clamping workpiece, take off clamping wrench.

The machine is provided with one set of jaws stepped inward and one set stepped outward.




Dimensions, Chucking Devices EMCO Chuck, dia. 85 mm

Outside stepped jaws




Pay attention to instructions on service and maintenance tips and to safety tips.
An instruction book comes with each chuck.

Inside stepped jaws



Soft jaws




Measures in mm !

2. Clamping devices for tools

Collet holder ESX 16

The collet holder serves to accomodate collets ESX 16.



Assembly:

- Insert the collet (1) at an angle into the clamping nut (3) so that the eccentric ring (2) engages the groove of the collet.
- Screw collet with clamping nut onto the collet holder (4).
- Insert tool into collet.
- Tighten clamping nut with sickle spanner.

Dismantling the collet:

Undo clamping nut.

While the nut is being unscrewed, the collet is pushed out by the eccentric ring in the clamping nut.


Care:

Before and after use clean and oil collets and collet holders. Chips and dirt can damage the clamping taper and cone and reduce precision.

Collet size (nom. \varnothing)	Clamping range
1.0	0.5 - 1.0
1.5	1.0 - 1.5
2.0	1.5 - 2.0
2.5	2.0 - 2.5
3.0	2.5 - 3.0
4.0	3.0 - 4.0
5.0	4.0 - 5.0
6.0	5.0 - 6.0
7.0	6.0 - 7.0
8.0	7.0 - 8.0
9.0	8.0 - 9.0
10.0	9.0 - 10.0

The milling cutter clamping fixtures

The milling cutter fixtures are used for clamping tools with a shaft diameter of 10, 12 and 16 mm.



Mounting of tools:

Put tool (1) into milling cutter clamping fixture (2) and tighten with both set screws M 6 x 6 (3).

Note:

When clamping tools in the collet mind the correct length of the tool for workpiece machining.

milling cutter fixture \varnothing 10 mm

- NC-centre dull \varnothing 10 mm
- spindle drill \varnothing 10 mm
- slot milling cutter
- end-milling cutter for T-slots 12.5 x 6 shaft \varnothing 10 mm
- end-milling cutter for T-slots 16 x 8 shaft \varnothing 10 mm

milling cutter fixture \varnothing 12 mm

- spindle drill \varnothing 12 mm
- radius milling cutter \varnothing 12 mm
- angular milling cutter 16 x 4, form A and B with shaft \varnothing 12 mm

milling cutter fixture \varnothing 16 mm

- end milling cutter \varnothing 16 mm

Holders for taps


Holders for taps are ready for delivery in three different sizes.

Holders for taps M3

Holders for taps M4

Holders for taps M5, M6, M8

The length compensation (push - pull) is 13 mm.




Mounting:

Put tap (1) into the square (2) of the tap holder (3) and clamp with set screw M 5 x 6 (4).

Shell end mill arbor

The shell end mill arbor is used for clamping the shell end mill $\varnothing 40 \times 20$ and the circular saw blade $\varnothing 60$.



Mounting:

- * Put spacing collars (1) on shell end mill arbor (2).
- * Put on tool (clamping screw must contact milling cutter or circular saw blade and not lower end base of the shell end mill arbor).
- * Tighten clamping screw (3) with wrench.

3. Coolant device

Caution:

Prisor to connection switch off machine and disconnect power supply.

The basic equipment contains a discharge hose (1) for the coolant.



Procedure:

- * The coolant tank is placed on the floor. (When using an Emco machine base, place the coolant tank below the machine base.)
- * Connect discharge hose (1) at the outlet holes (2) on the machine base (first take off drain plug from outlet hole).


Note:

When using an Emco machine base the discharge hose must be led trough the machine base (bore in table).

View: machine from below



- * Take off rear machine cover.
- * Take off cover for coolant hose, put coolant hose (3) onto open hole and tighten from machine interior.




- * Insert the below end of the discharge hose (1) into the coolant tank. (Shorten discharge hose so that it discharges vertically into the coolant tank).
- * Connect tube (6) on coolant pump and coolant tube, (on the back side of the machine, there is a breaking through to introduce the inflow hose).
- * El. connection instructions to be found in chapter "Electrical connection of accessories"
- * Position 5 is the cable for el. connection .
- * Mount rear cover of machine.



4. Machine Base

The stand for the control can be turned
90°.

Sizes of tables: See illustration



The stand for the control(1) can be mounted to the left or to the right side of the machine stand. The joint(2), the handle(3) and the legs(4) have to be mounted in the correct way.



Adjusting the Height of the Machine Stand

- Adjust the height with the hexagon screws M16 x 60 (5).
- Counter the hexagon screw with the hexagon nut M16(6).

Note:

The hexagon bolts can be placed directly on the floor, but it is advisable to place metal sheets (7) underneath.

Chapter G

Maintenance

- | | |
|--|---------|
| 1. Maintenance outline | G1 |
| 2. Lubricating and oiling | G2 - G3 |
| 3. Lubricant and coolant recommendations | G4 - G5 |

1. Maintenance outline

Routine check and maintenance intervals

1.1 Oil tank for central lubrication

Weekly check (see also following pages).

1.2 Water separator for compressed air

Weekly check (see also page B 18).

1.3 Tool shop slide

Oil daily (see following pages).


When lubricating the tool shop slide take care that oil does not drop on the main driving belt.

1.4 Gears

No greasing or oiling.

2. Lubrication and Oiling of the Machine

1. Cross, longitudinal and vertikal slides




The longitudinal and cross slides are supplied with slideway oil by the central lubrication system. For this purpose the pump for central lubrication is activated at certain intervals and a specific quantity of oil fed to the lubrication points via metering elements (1).

Oil grade: slideway oil (see lubricant recommendations).

The lubrication intervals and the pump running time is set by the works. After slide travel of 10 m the pump is switched on for 5 sec.

Oil Consumption:

Every 10 m of total travel of the slides a lubrication pulse is emitted by the control. Approx. 0,2 cm³ of oil per lubricating pulse are pumped to the lubrication points. The oil consumption per hour depends on the travel of the slides.



Venting the Lubricant Lines

If air enters the lubricant line owing to too low an oil level in the lubricant tank, the lubricant line must be vented. (air locks can be seen in the lubricant lines downstream of the metering elements).

For venting, unscrew the lubricant line upstream of the metering elements. Switch on lubricant pump and let it run until oil emerges from the unscrewed lubricant line. Retighten lubricant line.

Notes on Venting:

After the lubricant pump has been switched on, alarm A03 appears (pressure too low in the lubricant line). Cancel alarm A03.

Then activate lubricant pump until the air locks have escaped from the lubricant lines.

2.2 Feed spindle

The mounted feed spindles are greased for life time. A new mounted spindle has to be greased. (Grease quality: look lubricant recommendations)


2.3 Main spindle bearings

The main spindle bearings installed are greased for their entire service life.

2.4 Tool shop slide

Tool shop slide (1) to be oiled daily with slideway oil.

Take care that no oil drops on the main driving belt.




3. Lubricant- and Coolant Liquid Recommendations

The reference temperature for the viscosity details is 40°C (ISO VG), the reference temperature according to DIN is 50°C.



Slideways

Slideway oil with adhesive additives and wear-reducing additives. Prevention of the stick-slip effect. 73 mm²/sec. (cSt) at reference temperature 40°C. CASTROL MAGNA BDX 68. Complies with Cincinnati Milling Specification P 47.




Greasing Points

Greasing Points of the Feed Spindle

Lithium saponified multipurpose grease with high dropping point. Penetration about 285. NLGI Class 2. CASTROL SPHEEROL EPL 2. This grease has an operating temperature range of - 30°C to + 110°C.

Or

CASTROL GREASE LM -
Lithium saponified multipurpose grease of NLGI Class 2.





Coolant

CASTROL SYNTILO R - biostabile long-term coolant lubricant. No adhesion, skin compatible, excellent corrosion protection, neutral odour. High wetting and cooling action, can be used for every type of material. Recommended mixing ratio 1 : 30.



CASTROL CLEAREDGE EP - for true-to-size machining with high surface finish, combined with long tool times between overhauls. Recommended mixing ratio 1 : 30.

The products CASTROL VARIO HDX
CASTROL MAGNA BDX 68
CASTROL SYNTILO R

are attuned to each other,
and are available as the
COMPLETE CASTROL SYSTEM.

Special Note:

The required lubricating oil and media can be obtained in the trade (with the particular national or federal organisations of the petroleum companies). These recommended oils and greases differ in principle from the products available at filling stations.

Chapter H

Expansions

Chapter I

List of wearing parts

Chapter J

Readjustment works

- Repairing the step motors J1 - J2
- Replacing the X-, Y-, Z-slides J3 - J7
- Readjustment of the slide clearance J8 - J11
- Measuring the reversal clearance J12 - J13
- Replacing the door VMC-100 and
exchanging the gas spring J14
- Readjustment of ball snap for tool
turret positioning J15
- Control of carbon brushes on
main drive motor J16
- Changing of the bulb in the
machine lamp J17
- Re-adjusting the collet stroke J18


Replacing the step motors (Exchanging the toothed belts)

Note:

Disconnect the main plug prior to installation or removal of the step motors.

Removing:

(using X-step motor as example)




- + Dismount earthing cable (1).*
- + Unscrew the four socket head screws M6 x 40 (2) and remove belt guard (3)
- + Dismount step motor with base plate by unscrewing the four socket head screws M6 x 12 (4).
(In case of Y-step motor remove back panel and lower side guard before, in case of Z-step motor remove both protection sheets before)
- + Remove belt (11)
- + Unscrew motor from base plate (3).*
- + Loosen set screw M6 x 6(6) and pull off motor pulley (7) from motor stub.*
- + Unscrew step motor cover (8) and disconnect cables below.*
- + Loosen cable screw union (9) and unthread cables.*
- + Dismount cooling element (10) from step motor.*
- + Clean the bearing surfaces adjacent to the two paper seals (12,13).

Attention:

The Y-step motor can only be exchanged as a mounted group consisting of the step motor, motor plate and sealing.

- * These items do not apply for belt exchange.



Fitting (by the example Y-step motor)


- + Mount cooling element (10) onto step motor.*
(Mind: Lubricate cooling element before in any case using approx. 2 cm³ heat-conductive paste).
- + Screw motor plate (5) onto step motor.*
(Insert paper seal 13).
- + Place motor pulley (7) onto motor stub and tighten with set screw M6 x 6(6).*
(Set screw M6 x (6) to be secured with Loctite.)*
Note: During fitting mind the distance from shim ring to motor front.
It is 3,5 mm.
- + Insert cable in step motor and clamp cable screw union (9).*
- + Connect cable in step motor (see table).

Wire Nr. color	step motor X
1 white	0
2 black	8
3 blue	6
4 brown	4
5 green	2
6 red	9
7 violet	7
8 pink	5
9 orange	3
10 transparent	1
green/yellow	earth (protective conductor)

Wire Nr. color	step motor Y
1 white	0
2 black	8
3 blue	6
4 brown	4
5 green	2
6 red	9
7 violet	7
8 pink	5
9 orange	3
10 transparent	1
green/yellow	earth (protective conductor)

Wire Nr. color	step motor Z
1 white	0
2 black	8
3 blue	6
4 brown	4
5 green	2
6 red	9
7 violet	7
8 pink	5
9 orange	3
10 transparent	1
green/yellow	earth (protective conductor)

- + Connect earth cable green/yellow (1) at the outside of the step motor.*
- + Screw housing cover (8) onto step motor.*
- + Insert pulley (11).
- + Place down step motor with base plate and screw in the four socket head screws M6 x 12 (4). (Do not tighten yet; insert paper seal 12)
Mind: In case of Z-step motor lubricate the two support jaws of the motor plate sufficiently on top and below with heat-conductive paste.
- + Tension pulley and tighten socket head screws M6 x 12(4).
(For pulley tensioning press the step motor with approx. 10 - 15 N).
- + Check the distance between the proximity detector (14) and the limit switch sheet (15). This distance has to be 0.5 mm (If necessary, readjust, tightening torque max. 6 Nm).
- + In case of Y-step motor remount back panel and lower side guard, in case of Z-step motor remount the two guard plates.
- + Remount pulley guard (3).
- + These items do not apply for belt exchange.



Replacing the X-, Y-, Z-spindles

The spindles are only replaced as a group. The group consists of the spindle, nut mount, bearing pedestal and pulley (see Spare Parts List). With the bearing and mounting, ensure that the spindles are not bent.


Under no circumstances may the spindles be screwed on by the nuts, since this will cause the balls to fall out.

Removal:


General:

Dismantle the particular step motor with the motor plate. On the X step motor, additionally dismantle the belt protection first.

Removal of the X-spindle



To simplify spindle disassembly, traverse the X-slide as far as possible in the X-direction.





- + Unscrew the cheese-head bolts M5 x 25 (1) on the bearing pedestal.
- + Unscrew the hexagonal bolts M6 x 12 (2) for the nut mount.
- + Withdraw the spindle (3).

Removal of the V-spindle

Note:

To simplify spindle disassembly, traverse the Y-slide as far as possible in -Y direction.




- + Remove back panel.
- + Remove lower side guard.
- + Unscrew the four oval-head screws M6 x 10(2) for protective sheet 2 (3) and push back the protective sheet.
- + Unscrew socket head screws M5 x 25(4) on the bearing pedestal.
- + Unscrew socket head screws M6 x 12(5) for nut mount.
- + Pull out spindle (6).

Removal of the Z-spindle

Notes: When the step motor of the Z-spindle is removed, the vertical slide might slip away (the ball screws are not self-locking).

For this reason, securely support the vertical slide in the upper position prior to removal of the step motor (also installation and removal aid).

Do not unscrew the support plates (36) of the Z-spindle, otherwise the accuracy is impaired in case of reassembly.



- + Dismount protective sheets for Z-step motor.
- + Unscrew oval-head screws M6 x 10(33) for holding plate (37) and remove the holding plate (37).
- + Unscrew oval-head screws M6 x 10 (33) for stripper plate and remove stripper plate (41) with stripper felt (16).
- + Unscrew the two socket head screws M6 x 12(22) for bearing pedestal.
- + Unscrew socket head screws M5 x 40(40) for nut mount and pull out the spindle (38).

Installation of the spindles

Grease the spindles prior to installation.

Grease quality:

(See operating instructions, chapter "Lubrication".)


Installation of the spindles

The spindles must not be installed in distorted state.


Consequences of distorted spindle installation

Rapid wear, damage, balls break out.

Possibilities of distortion as in the example of the X-spindle




Distortion in plane 1
(plan view)



Spindle distorted on the side


Distortion in plane 2
(front view)




Spindle distorted in height

To prevent tensioning of the spindles during installation, the following procedure generally applies

(X spindle example)



- + Thread spindle, screw bearing pedestal (2) with cheese-head bolts M5 x 25 (3) firmly, so that it is centrally placed in the milling out.




- + Screw the nut mount (1) with the hexagonal bolts M6 x 12 (4) firmly.

Move slide or adjust nut mount so that it can be fastened with the hexagonal bolts.

- + Crank the slide completely to the right.

Keep the distance between the nut mount - bearing pedestal, as small as possible.




It is now possible that the spindle is tensioned in the elevation (level 2).

Remedy:

- + Loosen the bearing pedestal hexagonal socket head screws (3), which will cause the spindle to align itself in level 2.

Retighten the cheese-head bolts (3) of the bearing pedestal.



Possibility:

Spindle tensioned in level 1.

Therefore:

- + For safety, again loosen the bolts of the nut mount, and then retighten. (possible tensioning of the spindle in level 1)
- + Refit the remaining removed parts.

Readjustment of the slide clearance

- + Readjust the slide guides after extended use.
- + The wear of the guides on the X, Y, Z slides can differ considerably, since the load normally differs on the slides.
- + Slides with excessive clearance, can cause jerking during machining.
- + The clearance is set with two taper gib strips each per slide.



Checking the guide clearance of the X, Y, Z slide

Structure of the gauge:

The slide clearance is measured on both sides of the particular slide, and should not exceed 0.015 mm. During clearance measurement, the slide is swivelled to and fro at the particular measuring point, with a swivel force of 100 N (10 kp).



a) X slide

Gauge on Y slide
(If the gauge were fixed to the base, the Y clearance would also be measured)





b) Y slide

Gauge on base



c) Z slide

Gauge on measuring table




The gauge is only applied at the front, since the slide is guided at the rear by scraper felt.

Readjusting the taper gib strips

The slide clearance is readjusted with the appropriate taper gib strips on the slide.

The guide way of the taper gib strip, as well as the taper gib strip, are conical.

By screwing in the tapped stud (size 2.5), the taper gib strips are moved in the direction of the arrow. The clearance is reduced.



Process:

Readjust the tapped stud slightly.

Measure the slide clearance with a gauge.

Repeat process until the measurement obtained is 0.01 to 0.015 mm.


Attention:

Where the taper gib strips are excessively readjusted, the table will be clamped or will be very difficult to move.

The torque of the step motor could then be inadequate for traversing the slide. The step motor could lose the steps (feed force of the step motor is about 1300 N (130 kp)).


For this reason, unscrew the slide from the appropriate nut mount, and move slide backward and forward by hand.

Position of the taper gib strips




X taper gib strips

The taper gib strips on the X slide are freely accessible.



Y taper gib strips

Remove protective plates 1 and 2.




Z taper gib strips

The upper taper gib is freely accessible due to bores at the stripper plate.

To reach the lower taper gib, stripper plate (1) and stripper felt (2) are to be dismounted.


Removing the nut mount for manual movement of the slide:

To measure the slide clearance, unscrew the slides from the nut mount. Move the slides to and fro by hand. The movement force should not exceed 150 N (15 kp).




X slide:

Unscrew both hexagonal bolts M6 x 12 (1).



Y slide:

Remove the protective plate 2 (3) and unscrew the hexagonal socket screw of the nut mount (2).



Z slide:

Remove mounting plate (4), scraper plate (5) and scraper felt (6), and then unscrew both hexagonal socket screws of the nut mount (7). (Support Z slide!)

Measuring the reversal clearance

In addition to the slide clearance, the reversal clearance is important for operating accuracy.

The reversal clearance arises when traversing the slide, e.g. + direction to - direction.

In this case, the control indicates a traverse path, however the slide does not actually traverse (dead path).

The reversal clearance is measured about 5 - 30 mm prior to both the limit positions of the particular slide, and should not exceed 0,02 mm.

Measuring the reversal clearance

- + Fasten gauge with magnetic base.
- + Move slide to gauge.
- + Set gauge at 0.
- + Set display at 0.
- + Move slide about 1 - 2 mm toward the gauge (gauge and display indicate the same traverse path).
- + Move slide with control back to 0.
- + Read off difference (= reversal clearance) on the gauge.
- + Repeat process for the other limit position of the particular slide.

Attention: Relationship slide clearance - reversal clearance


The stronger the setting of the guide strips, the smaller the slide clearance will be, and the larger the reversal clearance.

Accordingly, the slide clearance and reversal clearance must be jointly adjusted. The particular tolerances for slide clearance and reversal clearance, must not be exceeded.

Adjustment of the reversal clearance


You can reduce the reversal clearance by loosening the taper gib (slide clearance gets larger at the same time).

Assembly of the gauge for measuring the reversal clearance of the slide




X slide

Gauge on the Y slide



Y slide

Gauge on the base




Z slide

Gauge on the table

Replacing the door VMC-100 and exchanging the gas spring

Note:

To replace the door and gas spring, move door into uppermost position.



1. Replacement of door

A) Removal

- + Unscrew the two flat head screws (1).
- + Unscrew the four flat head screws (6) from guide element (4) and remove door (3) together with cover plates (2).
- + Unscrew socket head screws (5), remove plate (15), plate (7), distance sleeve (8) and handle (9).

B) Installation

- + According to removal, but in reverse order.
- + Stick on rubber strip (16).

2. Exchanging of gas spring

A) Removal


- + Unscrew hinge bolt (10).
- + Take off locking ring (11).
- + Remove limit switch protection (12).
- + Remove switch sheet (14).
- + Remove gas spring (13).

B) Installation

- + According to removal, but in reverse order.

Readjustment of ball snap for tool turret positioning

According to the duration of use it might happen that the tool turret will not stop any more in snap-in position. For this reason the ball snap has to be adjusted again.




Procedure:

A weight of 30 N (see sketch) is to be mounted on the tool turret.

Then adjust set screw M10 x 10 (1) for ball snap until the tool turret including the weight will not turn automatically any more.



(Beforehand, dismantle the pinion (2).



Control of carbon brushes on main drive motor

Mind:

Switch off machine before
checking the carbon brushes.



Interval:


Check the four carbon brushes (5)
every 6 months.

If the wear limit of 6 mm is achieved
on one of the four carbon brushes,
all four carbon brushes have to be
replaced by new ones.

Changing of the bulb in the machine lamp

Warning:

Disconnect mains plug before
changing the bulb.




Dismantling:

- Remove rear cover of machine.
- Dismantle machine lamp from machine.
- Unscrew setscrew (2) and remove deep bowl reflector (3).
- Change bulb (4).

Assembly in reverse order to dismantling.

Re-adjusting the collet stroke

If the tang (1) can no longer be introduced into the collet (2), the collet stroke must be re-adjusted.



Procedure:

- Move clamping bracket (3) into lowered position (collet opened).
- Loosen lock nut (5) of the clamping screw (4).
- Re-adjust clamping screw (4) until the plug gauge supplied as a basic accessory is still just accommodated.
- Turn the clamping screw (4) about a further 90° and lock again in this position.